

MOTOROLA VISAR



MOTOROLA VISAR SPECIAL BUTTONS:

SCAN:

MOMENTARY PRESS - TURN SCANNING ON OR OFF
LONG PRESS (BEEPS) - ENTER SCAN PROGRAMMING LIST

MONITOR:

MOMENTARY PRESS - DEFEATS RECEIVE PL WHILE PRESSED
LONG PRESS (BEEPS) - DEFEATS RECEIVE PL UNTIL PRESSED AGAIN

SCAN PROGRAMMING:

1. RADIO SHOULD NOT BE SCANNING. (TURN RADIO OFF THEN BACK ON)
2. PRESS AND HOLD SCAN BUTTON UNTIL RADIO BEEPS
3. MOVE THROUGH CHANNELS WITH ARROW BUTTONS
LED OFF - NOT IN SCAN LIST
LED GREEN - SCAN NON-PRIORITY
LED RED - SCAN PRIORITY
4. TO ADD OR DELETE A CHANNEL PRESS THE MONITOR BUTTON
REPEATEDLY TO TOGGLE THROUGH LED OFF, LED GREEN OR LED RED.
5. REPEAT STEPS 3 AND 4 AS NEEDED.
6. PRESS THE SCAN BUTTON TO EXIT SCAN PROGRAMMING MODE

Note: The side buttons must be programmed for these functions to enable scan programming via RSS.